

CAMPY飛輪改裝片安裝方法

●30t改裝片安裝法

- 將30t gearoop飛輪改裝片置入棘輪座，而後置入飛輪墊片於30t外側。
- 將原飛輪的“齒距一齒變兩齒的齒片”抽掉，維持齒距由小變大。例如：
12(1)13(1)14(1)15(1)16(2)17(2)19(2)21(2)23(2)25(2)27 ()內數字為齒距
—> 12(1)13(1)14(1)15(2)17(2)19(2)21(2)23(2)25(2)27(2)30 此例必須抽16t
- 將調整後的原飛輪置入棘輪座，並且鎖上飛輪蓋，即可作動。

p.s 適用原飛輪最大齒數為25t or 27t

<註> 裝置此改裝片必須和擺臂以及鏈條一起做調整，若自身無改裝經驗建議找專業店家做改裝。

●32t改裝片安裝法

- 將32t gearoop飛輪改裝片置入棘輪座，而後置入飛輪墊片於32t外側。
- 將原飛輪的“齒距一齒變兩齒的齒片”抽掉，維持齒距由小變大。例如：
12(1)13(1)14(1)15(1)16(2)17(2)19(2)21(2)23(3)26(3)29 ()內數字為齒距
—> 12(1)13(1)14(1)15(2)17(2)19(2)21(2)23(3)26(3)29(3)32 此例必須抽16t
- 將上述調整後的原飛輪置入棘輪座，並且鎖上飛輪蓋，即可作動。

適用：原飛輪最大齒數為27t or 29t

<註> 裝置此改裝片必須和擺臂以及鏈條一起做調整，若自身無改裝經驗建議找專業店家做改裝。

Campagnolo Modified FreeWheel Manual (30t.32t)

● 30t Modified FreeWheel

- Insert the 30t into the Cassette body, and then insert the SPACER.
- Take the piece which is the position from 1 tooth different to 2 tooth different away. To keep the tooth different order.

EX:

12(1)13(1)14(1)15(1)16(2)17(2)19(2)21(2)23(2)25(2)27 (x)is the tooth different
—> 12(1)13(1)14(1)15(2)17(2)19(2)21(2)23(2)25(2)27(2)30 16t out in this case

- Insert the original FreeWheel into the Cassette body, and tighten the Cover.
- The last step would be ADJUST. You might need to adjust the chain and the derailleur cage as well.

Fit Original 11-25; 12-25; 11-27; 12-27, and get a new ratio.

● 32t Modified FreeWheel

- Insert the 32t into the Cassette body, and then insert the SPACER.
- Take the piece which is the position from 1 tooth different to 2 tooth different away. To keep the tooth different order.

EX:

12(1)13(1)14(1)15(1)16(2)17(2)19(2)21(2)23(3)26(3)29 (x)is the tooth different
—> 12(1)13(1)14(1)15(2)17(2)19(2)21(2)23(3)26(3)29(3)32 16t out in this case

- Insert the original FreeWheel into the Cassette body, and tighten the Cover.
- The last step would be ADJUST. You might need to adjust the chain and the derailleur cage as well.

Fit original 11-27; 12-27; 11-29; 12-29